

## **INSTALL INSTRUCTIONS**

**Rear Stealth Bumper** 

Product: 6211R0B

**Application: 2021+ Ford F-150** 



#### **WARNING**

Read the instructions completely before beginning installation. Before tightening bolts, drilling or cutting where required, check to make sure there are no obstructions such as brake, fuel or electrical lines which may be damaged. Also keep in mind this is an aftermarket product and MAY require minor shimming and/or trimming, reaming, etc. for proper fit. Road Armor is not responsible for any damages to vehicle.

#### **(1) IMPORTANT NOTICE**

- Be sure to inspect and test fit your product to ensure proper fitment before having it coated, painted, bed lined, etc.
- Road Armor will not be responsible for the cost of coating your unit if any problems with fit or finish are not noted and addressed beforehand.

### **SAFETY FIRST!**

- FOLLOW ALL INSTRUCTIONS, YOUR SAFETY AND THE SAFETY OF OTHERS IS MOST IMPORTANT.
- WEAR APPROPRIATE EYE PROTECTION AND EXERCISE CAUTION WHEN DRILLING / CUTTING

12

## **REQUIRED TOOLS**

Metric and SAE Socket Sets and Wrenches

EM NO.

PART NUMBER


37407

DESCRIPTION

#10-24 Zinc Finish Steel with External Tooth Lockwasher K-Lock Nut Tape Measure

Cut off wheel

# INCLUDED HARD-WARE
















- Remove sensors and Plugs from factory bumper. Leave Wiring Harness connected to Hitch.
- 2 Remove 5 bolts per side as shown
- Using a ratcheting wrench ideally, remove bolts next to license plate lights
- There are 4 tabs that need to be pushed through bracket to remove the bumper
- Trim bracket on receiver hitch. Lower trim is necessary for bumper installation.
- 6 Use a jack to support receiver hitch.
- Retainer washers are holding the three bolt tabs and must be hammered out
- Remove OEM Triple Nut Plate one side at a time.
- 9 Cut OEM Triple Nut Plate as shown. Repeat Step for Both Sides





















- 11 Install Double Nut Plates, Hitch Plate, Road Armor Logo, License Plate Lights, Spare Tire Lock, License Plate, and SRM Lights
- 1) Measure side to side on bumper and adjust brackets if needed.
- 13 Install bumper using supplied 1/2" hardware checking bumper alignment and tighten down. Once Tight, Connect All sensors and Lights.

